



Step 1
Attach the suspension plate to the wall.



Step 2
Connect the lamp body's cable to the power cable.




Step 3
Hang the rings on the hook.




Attention!!!

- 1: Before installation, please check if the package is complete and if the lamps are in good condition.
- 2: Cut the main cable before installation. If the wiring is already in place, install the lamp body first, then the power supply.
- 3: Installation and maintenance must be carried out by professional technicians.




- 1: Drill the mounting holes according to the ceiling of the suspension plate.
- 2: Hammer the expansion tube into the mounting hole.



Secure the suspension plate to the ceiling with screws.



The power cable and lamp wire are connected, and the connection must be firm, no wrong connection.



Insert the wire and terminal into the ceiling cup and connect the ceiling cup and the hanging plate with screws.

Maintenance Instructions

When maintaining the luminaire, be sure to disconnect the power supply to avoid electric shock.

- 1: For effective and safe use of this product, you should regularly inspect and maintain the luminaire. When inspecting, ensure that the connecting parts of the luminaire body, pre-installed parts, and suspension hooks and chains on the ceiling are securely fastened to prevent unnoticed damage.
- 2: When the light source needs to be replaced during cleaning, it is recommended to choose a brand product with good quality and long service life to avoid the additional effort of replacing the light source.
- 3: When cleaning the lamp, do not rotate the lamp body to prevent the external threads of the lamp body from loosening, which may lead to unsafe accidents.
- 4: When wiping the lamp bead, it is recommended to use warm water to dilute the cleaning cloth, and gently wipe the surface of the crystal bead (wipe from top to bottom). When all the water bead lamps are removed, pay attention to the balance of the lower water bead lamp body, and must be balanced during disassembly, otherwise it will tilt and deform the lamp body.
- 5: When wiping the lamp body bracket, use a soft cloth without running water, especially not with alcohol, gasoline, etc. If the lamp bead rusts or the crystal bead is defective, it should be replaced in time.