

- (1) Cable Connection
- (2) Power Cable
- (3) Bracket
- (4) Self-tapping Screw
- (5) Nut
- (6) small deco knob
- (7) big deco knob
- (8) Bracket Screw
- (9) Grounding Cable
- (10) Nut
- (11) Toothed Washer
- (12) Base
- (13) Small Decorative Button
- (14) Cap
- (15) Safety Screw
- (16) Chain
- (17) Triangle Hook
- (18) Hanging Ring



Image 1

- 1. Secure the bracket (3) tightly to the ceiling with self-tapping screws (4)
- 2.Please pay attention to the L and N wires during wiring, the connection should be very tight, and the plug should not fall off when pulled.
- 3.Insert two bracket screws (8) through the base (12) and secure them with two small decorative buttons.

Image 2

- 1.Attach the triangle (17) to the ceiling with screws (7), then attach the hanging loop (18).
- 2. Connect the hanging loop (16) and the chain (18) together.
- 3. Thread the power cable (2) and grounding cable (6) through the chain, the ring (18), upper cover (14), threaded tube, etc.
- 4. After connecting the power cable, slide the canopy towards the ceiling and tighten the safety screws.

Image 3
Assembly as in Image 1.

