To Users

Thank you for purchasing this ligh;

For your safety, please hire a professional installer.

Warining

Please strictly follow the installation instructions Improper installation may result in safety hazards such as crushing and electric shock.

All power supplies should not exceed the specified range (rated voltage AC 110V-240V +10%, frequency 50Hz)

To avoid unnecessary losses to users or safety accidents such as electrical leakage

Do not install on weak ceilings or in open space


To avoid unnecessary losses to users or salery accidents such as electrical leakage

Do not install the lamp over hot objects or in humid places

To prevent damage to the lamp's components, resulting in abnormal conditions during use

If any abnormality occurs to the lamp, please disconnect the power immediately and contact the dealer

The model of the lamp should be probided during maintenance, and the model can be confirmed by refering to the label on the lamp body.





Unstable ceilings Open-air placesHigh temperature and humid areas

Installation Instructions:

Installation method:

Caution:

Must ask a professional electrician installer, after weighing and testing the light fixture lamps, scratch the lamp body with an extended bollard during installation according to the environment of the installation location.

A: Test light can be illuminated normally;

B: Pegboard fixed to the ceiling;

installation to prevent electric shock

C: The luminaire is firmly fixed to the pegboard;

Note: Be sure to disconnect the power supply before

D: The lampshade is slowly released so that it lies flat, the installation is complete.